

Inspection Program



Australian Standards recommend the life of a harness to be 10 years from the date of manufacture, if no damage has been sustained prior or in the meantime. Inspection by a competent person is recommended every 6 months in accordance with the manufacturer's recommendations.

The harness is to be withdrawn from use if it shows any form of degradation during this inspection.

Refer to AS/NZS 1891.4:2009 for further guidance on harness selection, use, inspection and maintenance.

Before and after each use, inspect your harness for any signs of ageing or damage.

1. Run your hands over the straps and ensure all webbing is free from abrasion, dirt, cuts, tears, burns and pen marks, overspray, chemical and UV damage, worn or crushed fibres, discolouration and knots.
2. Check the harness' sewn areas for damaged stitch patterns, broken or loose threads, heat damage or stretching.
3. Check each buckle, D-ring or attachment point is in perfect working condition with no distortion, cracking, corrosion, rust, abrasion or missing components.
4. Ensure all labels and tags are present and clearly legible. If any defects are found during this checking process you should remove the harness from service immediately and tag it "Out of Service". If more than 10% wear is determined, tag the unit and remove it from service.





Which harness is right for you?

Harness	AS/NZS 1891.1:2007 Certified	Front & Rear Fall Arrest Attachment	Waist Belt / Side D Rings / Pole Strap Attachment	Dorsal Extension	Gear / Tool Loops	Confined Space Retrieval	Padded Legs/ Back Support	Padded Seat Support	Construction & Maintenance	Elevated Work Platform	Hot Work / Flame Retardant	Rope Access and Rescue	Tower Work	Reflective (R) & Luminescent (L)	PFD Personal Flotation Device
Ferno Ultralite X Harness	■	■				■	■		■	■				R	
Ferno Challenge Pro	■	■	■			■	■		■	■		■		R	
Ferno Challenge Pro with PFD	■	■	■			■	■		■	■		■		R	■
Ferno Challenge Pro Flame Retardant	■	■				■	■		■	■	■				
Ferno Centrepont 2 Harness	■	■	■		■	■	■					■	■	R	
Ferno Centrepont II Harness with Ascender	■	■	■		■	■	■					■	■	R	
Ferno Hardpoint Harness	■	■	■		■		■					■	■	R	
Ferno Hardpoint Harness with Ascender	■	■	■		■		■					■	■	R	
Ferno ROAR Lite Harness	■	■			■	■	■					■	■	R	
Ferno Advantage Pro Tower Harness	■	■	■	■	■		■	■				■	■	R/L	
Ferno Tower 5 Harness	■	■	■	■	■	■	■	■					■	R/L	
Ferno Hottie Flame Retardant Harness	■	■							■	■	■				
Ferno Tradesman Full Body Harness with Accessories	■	■	■	■		■			■	■		■		R	
Hi-Safe FH17 Full Body Harness	■	■			■				■	■					
Hi-Safe FH50 Full Body Harness	■	■				■			■	■					
Hi-Safe FH50 Full Body Harness with Lanyard	■	■				■			■	■					
Hi-Safe FH10 Fall Arrest Harness	■	■							■	■					