

COMPONENT	MAINTENANCE	TIPS & PRECAUTIONS
POLE	 After use, fully extend the pole and clean/dry each section Check clamps and pole sections for damage Check clamps for correct torque and adjust accordingly Test associated tool attachments' end fittings for the correct mating with the pole's collar Ensure pole end protector is in place whenever pole is not in use 	 Dry storage will prolong the life of the pole and pole carry bag. A pole end protector should be placed on the gold collar to avoid damage.
BOAT HOOK	The sleeve fitting should be regularly tested on the pole top fitting	
BODY HOOK	The sleeve fitting should be regularly tested on the pole top fitting	
CARRAGO	Regularly check the karabiner spring retainerThe sleeve fitting should be regularly tested on the pole top fitting	
CENTRE PUNCH	The sleeve fitting should be regularly tested on the pole top fitting	
CHIMNEY EXTINGUISHER	The sleeve fitting should be regularly tested on the pole top fitting	
CLAMPING FLOAT	 Wipe dry after use and check the thread is clean and grit free Clean with warm soapy water if necessary 	Avoid dropping the float onto hard surfacesStore in Reach and Rescue Kit Bag
CONTAINER RELEASE	The sleeve fitting should be regularly tested on the pole top fitting	
CROOK	The sleeve fitting should be regularly tested on the pole top fitting	
FLOTATION COLLAR	 The sleeve fitting should be regularly tested on the pole top fitting Check the Velcro lasso system is clean and functions well Clean regularly to maintain high standards 	
GoPRO ADAPTOR	The sleeve fitting should be regularly tested on the pole top fitting	
GRAPPLER	The sleeve fitting should be regularly tested on the pole top fitting	
UNDERWATER INSPECTION CAMERA	The sleeve fitting should be regularly tested on the pole top fitting	
LADDER & GRAPPLER	 The sleeve fitting should be regularly tested on the pole top fitting Keep the ladder clean and check for any damage 	
LINE HOOK	The sleeve fitting should be regularly tested on the pole top fitting	Ensure the cross bar is closed prior to fixing a line
PRO SPRING SNARE	 The sleeve fitting should be regularly tested on the pole top fitting The sleeve and cable should be kept dry, clean and lightly oiled 	 If the spring of the cable reduces dramati- cally, contact the supplier
RESCUE NET	The sleeve fitting should be regularly tested on the pole top fitting	
ROPE BLADE	The sleeve fitting should be regularly tested on the pole top fitting	Ensure the blade is covered after use
SCAFF HOOK CARRAGO	The sleeve fitting should be regularly tested on the pole top fitting	
SONAR SEARCH FRAME	The sleeve fitting should be regularly tested on the pole top fitting	
RESCUE THROWBAG	 The sleeve fitting should be regularly tested on the pole top fitting Check terminal bag knot Air the rope after each use to dry Ensure the rope is correctly packed to allow correct deployment 	
TRIGGER BLADE	The sleeve fitting should be regularly tested on the pole top fitting	
WADING POLE HANDLE	The sleeve fitting should be regularly tested on the pole top fitting	
WADING POLE		
WATER ACTIVATED FLASH- LIGHT	If unused for extended period, check batteries are working and corrosion free	
WINDOW SMASHER	The sleeve fitting should be regularly tested on the pole top fitting	

