

IndustriPOD® Tripod Series

The IndustriPOD® tripod series are heavy-duty, versatile and durable tripods that exceed the criteria of most international standards. Both IndustriPOD® models have built-in safety factors equivalent to internationally recognised rescue systems.

The IndustriPODs' design and simplicity of use make these sturdy tripods ideal for any heavy-duty confined space requirement where guaranteed performance is mandatory.

For added versatility, IndustriPOD® is compatible with many Ferno Arachnipod Total Edge Management Accessories.



IndustriPOD®

IndustriPOD+®

INDUSTRIPOD® FEATURES

- Rectangular, adjustable legs with quick-action ball lock leg pins
- One-piece fabricated steel head
- One stainless steel M12 swivel eyebolt anchor point
- Three side plate anchor points
- Three tie-off points for rigging or stabilisation
- Adjustable feet with aggressive non-slip tread pattern
- Adjustable foot tether

INDUSTRIPOD+® FEATURES

- Rectangular, adjustable legs with quick-action ball lock leg pins
- One-piece fabricated steel head
- Two stainless steel 70 mm sheave pulleys allow two devices via cable or rope to be attached simultaneously
- Pulley detent pins to prevent rope / cable jump
- Three side plate anchor points
- Three tie-off points for rigging or stabilisation
- Adjustable feet with aggressive non-slip tread pattern
- Adjustable foot tether

Specifications

SPECIFICATIONS	IndustriPOD®	IndustriPOD®+
DESIGNATION	Tripod for securing persons who access or work in confined spaces where a fall from height may occur. Not intended or to be used for lifting equipment.	
WEIGHT	23 kgs	25 kgs
HEIGHT - Minimum	1650 mm	1750 mm
HEIGHT - Maximum	2465 mm	2565 mm
FOOT PRINT - Inside diameter of feet	2187 mm	2187 mm
FOOT PRINT - Outside diameter of feet	2523 mm	2523 mm
SAFE WORKING LOAD (SWL)	<ul style="list-style-type: none"> 550 kg off M12 stainless steel eye bolt 360 kg off side plate anchor points 	<ul style="list-style-type: none"> 220 kg pulley over leg 360 kg off side plate anchor points
RATING	2 Person Rescue / 1 Person Working	2 Person Rescue / 1 Person Working
TRIPOD CONSTRUCTION	Steel, aluminium and stainless steel	Steel, aluminium and stainless steel
STANDARD FOOT TREAD	Polyurethane	Polyurethane
LEG STOPPERS	Polyurethane	Polyurethane
PULLEY HEAD PULLEY SPACERS		Acetal
SUPPLIED IN THE BOX	<ul style="list-style-type: none"> IndustriPOD® Tripod Adjustable Foot Tether (1) User Instruction Manual 	<ul style="list-style-type: none"> IndustriPOD+® Tripod Adjustable Foot Tether (1) User Instruction Manual
WORKING LIFE	<p>The actual life span of the IndustriPOD cannot be predicted exactly, as it is influenced by many factors including but not limited to frequency and intensity of use, environment, weather, storage conditions, etc.</p> <p>For metallic products it is advisable to replace after 10 years, however the life span is theoretically indefinite, with strict adherence to the maintenance and inspection guidelines outlined in the product's User Instructions. If there is any doubt about the safety of a product, do not use and contact your safety representative or the manufacturer.</p> <p>It is always recommended to review the manufacturer's instructions as a life span may be restricted due to application or applicable product standards.</p>	

Optional Accessories



IndustriPOD® Bag
(36-1019)



Hold Down Stake
(26-2056-0)



Step
(07-1026-0)



Equipment Bracket
(90-0119)



Fall Arrest Block Adaptor (APOD-FBA)



Winch
(APOD-WINCH20M)
Requires APOD-FBA sold separately or together in a kit (APOD-WINCH20K)



IK Fall Arrest Adaptor
(90-0449)



Type 3 Rescue Recover Block (APOD-FAB25M)



Harken Lokhead Winch Bracket (APOD-HWAB)