

KNUCKL Rope Gripping Device





The KNUCKL rope gripper is a compact device that significantly increases the holder's grip on hand-held fibre rope while using a fraction of the normal effort.

Weighing a light 30g (10z), the ergonomically designed Knuckl fits comfortably in the hand and works equally well for left and right-handers, with or without gloves and on wet or dry rope. The Knuckl's cleat-style V groove is non-aggressive and kind to rope yet extremely effective in maintaining its grip on rope.

This durable device while small and lightweight, makes a powerful difference to the user when hauling or holding rope:

- Increasing grip and control of rope while reducing effort and fatigue
- Reducing the risk of rope burn or injury.

Made from glass-filled nylon, the Knuckl does not corrode, is long lasting and a cost-effective work aid for anyone handling rope within Fire and Rescue, Emergency, Arboriculture, Rope Access and other work at height industries. Available in red, the Knuckl Rope Gripping Device is supplied with a coiled lanyard to prevent accidental loss and for Dropped Object safety when used at height.

KNUCKL SPECIFICATIONS

Product Code	VAH-KNUCKL
Dimensions	85 x 50 x 20mm (3¼ x 2 x ¾ in)
Weight	30g (1oz)
Coiled Lanyard	Coiled Length: 40cm (16 in) / Extended Length: 120cm (48 in)
Material	Glass-filled Nylon
Colour	Red
Compatible Fibre Rope	Diameter Ø: 8mm - 13mm (5/16 x 1/2 in)

