

PRODUCT QUALITY STATEMENT

As part of our quality control procedure, we can confirm that this product has been carefully inspected and tested, to ensure that all the taped seams are waterproof, and that the garment is fully quality checked for any manufacturing or material defects.

The Flood Suit comes with a 12 month warranty against manufacturing or material defect, with the exception of the latex socks, which have a 3 month warranty due to the nature of the material.

If you should have any reason to complain about poor quality, in the first instance please contact our Service Centre - Email: service@safequip.co.uk

PRODUCT LIFESPAN INFORMATION

Dependent upon its usage, care/maintenance/storage, we would advise that an average product lifespan would be 5 years from date of issue.

PART NUMBERS

SAF10016 - Flood Suit

SAF10019 - Salopette

SAF10020 - Jacket

SAF10021 - Stowage Bag

SAF10023 - Twin Stowage Bag

Safequip Ltd (Service & Distribution Centre)

Unit 3 Brunswick Park
Brunswick Industrial Estate, Brunswick, Tyne & Wear NE13 7BA United Kingdom
Tel: +44 (0)1259 727835
Email: service@safequip.co.uk

Safequip Ltd (Registered Office)

Unit 5c Innovate at Earls Court, Earls Gate Business Park
Grangemouth, FK3 8ZE United Kingdom
Tel: +44 (0)1259 727835

Email: sales@safequip.co.uk Website: www.safequip.co.uk



SAFEQUIP FLOOD SUIT

User & Maintenance Manual

Product Code

SAF10016



EN 343

2003 + A1 : 2007 Class 1

Protective Waterproof Foul Weather Clothing

Specialist Rescue Equipment *by Professionals for Professionals*

USER INSTRUCTIONS

- Remove the suit from the stowage bag, and make sure you have a suitable area to don the suit as the latex socks could easily be punctured if a suitable area is not used.
- Adjust the salopette to fit by adjusting the waist belt and shoulder straps, to ensure a good fit.
- Make sure the front chest zip is closed and the elasticated drawstring cord is tightened, so that the top of the salopette fits snug around the chest area.
- To don the jacket, place over the head and adjust the waist band by using the adjustment tabs, and ensure that the jacket fits snug around your body.
- The neck can be left open or closed as desired. In hot conditions, it will be more comfortable to vent the suit.
- **IMPORTANT:** The Flood Suit has no integral buoyancy, so it is recommended that the Flood Suit is worn in conjunction with a Lifejacket or Buoyancy Aid, to aid in a total immersion situation.
- **IMPORTANT:** The Flood Suit is NOT a drysuit, so in total immersion scenarios, a small amount of water may enter the suit, however this will not affect the functionality of the suit.
- **IMPORTANT:** It is recommended to wear suitable clothing underneath the Flood Suit to provide thermal protection depending on the weather conditions.
- When removing the Flood Suit, make sure you release the waist band adjustment tabs and open the neck before removing the jacket. With the salopette either un-clip the shoulder straps or slip them off your shoulders and un-clip the waist belt before removal.

CARE INSTRUCTIONS

Following use, please make sure that you clean the Flood Suit thoroughly using fresh water or a mild detergent solution to remove any dirt or contamination. **IMPORTANT:** You must NOT use any aggressive chemicals such as bleach or similar, otherwise this could penetrate the fabric and cause the material to become porous.

- The Flood Suit should then be hung upside down and left to dry, ideally in a drying room or similar. (DO NOT DRY THE FLOOD SUIT OVER A RADIATOR OR NEAR RADIANT HEAT). Also do not leave out in hot sunshine for a prolonged period, as UV can be potentially damaging to the suit.
- When they are fully dry, please place the suit back into the stowage bag provided, and store in a location where it is not going to be damaged by sharp objects.

REPAIR INSTRUCTIONS

- Determine the location of the damage or leak. This can be done by wearing the flood suit in water and then checking inside for wet spots.
- For repair purposes, turn the suit inside out.
- At the location of the damage/leak, spread a smooth layer of glue over the damaged area, and also onto the repair patch provided. Allow both to dry for approximately 5 minutes until both areas have become tacky to the touch.
- Then place the patch over the damaged/leak area and apply pressure so that there isn't any air trapped between the suit and the patch.
- Then allow the repair to fully dry before reusing.